STREET TREE PLANTING DETAIL

CENTER OF TREE LINE

ARBOR TIE - TREE SPECIFIC
NON WIRE - NON HOSE

2-3" CEDAR STAKES SET
OUTSIDE OF ROOTBALL

REINSTALL EXISTING PAVERS
FLUSH TO CURB & SIDEWALK

2' SAND BEDDING COURSE

2" WASHED PEA GRAVEL

6" CURB

SIDEWALK

ROOT BARRIER
ALL FOUR SIDES

2" - 3/4"-0 AGGREGATE
BASE COMPACTED

50-50 DIRTHUGGER
TOPSOIL

TREE WELLS W/OUT PAVERS
BRING FLUSH TO SIDEWALK
AND CURB USING
50-50 DIRTHUGGER TOPSOIL

1'-0" MIN COMPACTED PLANTING
SOIL BENEATH ROOTBALL

TURN DOWN TOP 1/3 OF BURLAP. CUT AND
REMOVE. LEAVING REMAINING BURLAP
UNDISTURBED. IN PLACE.